TOOQ



iMOVE

FS20209M-B

User manual


FLOOR STAND WITH WEELS FOR 55”-100” SCREENS

VESA: 200x200, 200x300, 300x200, 200x400, 400x200, 300x300, 300x400, 400x300, 600x200, 350x350, 500x300, 400x400, 600x300, 500x400, 400x600, 600x400, 700x400, 800x400, 700x500, 600x600, 800x500, 800x600, 900x600, 1000x600


55”- 100” | 120 kg

EN


Content




A (x1)



B (x2)




C (x2)



D (x2)



E (x1)



F (x1)



G (x1)



H (x1)



I (x4)




J (x4)




K (x4)
M5x25




L (x28)
M6x12



M (x4)
M6x24



N (x8)
M8x20



O (x4)
M8x24



P (x5)
D5



Q (x4)
Ø15xØ8x10



R (x1)
14mm



S (x1)
4mm



T (x1)
5mm


Before installation

• Read the instruction manual, if you are in any doubt about the instructions or warnings, contact your local dealer.
• Make sure you have received all parts according to the components checklist for installation. If any parts are missing or defective, please contact your local distributor.




• Installation of heavier products may result in instability and possible personal injury.
• The brackets must be assembled as specified in the assembly instructions. Incorrect installation may result in product failure and serious personal injury.
• Proper safety equipment and tools must be used. This product should only be installed by professionals.
• Ensure that the mounting surface can safely support the total weight of the equipment and all its components.
• Use the supplied mounting screws and DO NOT OVERTIGHTEN THEM.
• This product contains small parts that could be a choking hazard if swallowed.
• Keep these products away from children. This product is intended for indoor use only. Outdoor use will not only damage the product but may also cause personal injury.
• Please refer to the product warranty here.

Installation




1

Installation




Installation


NOTA: After all the Screws are attached, tighten all of them.





Installation



Installation







Mounting level	Distance from the top of the brackets to the floor (X)
Upper	1635mm
Middle	1755mm
Lower	1875mm


Installation

⚠ CAUTION


To ensure a safe installation, select the proper screw before starting:
- *Use screws specified by the TV manual or manufacturer.*
- *Check length: **TOO LONG** damages the TV; **TOO SHORT** causes falls.*

***Note:** Use a hand screwdriver to prevent damage; power tools are not recommended.*
***DO NOT OVERTIGHTEN** the screws.*


***Note:** Ensure that both mounting arms are horizontally aligned and centered on the back of the TV.*



***Note:** Use spacers if the back of your TV is curved, recessed, uneven, or if the bracket plate does not sit flush against the TV.*



Installation




6a

Installation

⚠ CAUTION

Make sure to tighten the screw with Allen Wrench after attaching the brackets.

Make sure to hang the TV on the front side of the cart.



Warranty information

Since 1 January 2022, TooQ offers a 3-year warranty from the time of purchase, so it will always keep the purchase ticket or invoice containing the date of purchase. The distributor or retailer from whom you purchased the product will attend to your claim and offer technical service while the warranty is in force.

Out of warranty

The warranty does not cover damage or defects caused to the external enclosure due to:

- Not following the user manual.
- Modifications or alterations of any kind.
- High and low temperatures, humidity or contact with liquids.
- Worn and scratches caused by daily use.
- Use the product with any other device which is not the one indicated for its use. The warranty does not cover damage or defects caused to the hard drive by improper use of the hard drive or the external enclosure.

FAQ

You can consult the frequently asked questions from our website www.tooq.com on the product link. Products may be subject to variations due to stock changes, product improvements or printing errors. In case of doubt, please contact us.

Find out about all our news!

Follow us on social media

©2025 by TooQ Technology, S.L.
All Rights Reserved.
tooq.com